


## [Reading the display]

Besides regular timekeeping, this watch also has stopwatch and time memory (dual time zone) functions. Combinations are possible, but with only one function at a time.


The display converts from regular timekeeping to the stopwatch mode when the **ⓐ** button is pressed.

If the time memory has been activated, pressing the **ⓐ** button will display a second time, which can be set for any desired time zone.



NRS

## [Operating the stopwatch]




\* When the display is other than 0:00, press the **ⓐ** button for 2 seconds or more until 0:00 is displayed.

Regular timekeeping returns, if the **ⓐ** button is pressed, when using the stopwatch. However, the stopwatch mode works independently.


## [Working range]

In the stopwatch mode the display of minutes and seconds is limited to 13 minutes from which it automatically converts to the display of hours and minutes up to 13 hours. Thereafter it can be reset and started again.


## [Presetting the time memory (Dual time zone)]




[Readjusting errors up to ±30 seconds]



[Setting the time display (Example: 10:58 PM)]



[Setting the calendar display (Example: June 13 Monday)]



Note: As the calendar system is set at 28 days for February, reset March 1 to February 29 each leap year.