




## [Reading the display]




## [Readjusting errors up to ±30 seconds]



## [Setting the time display (Example: 10:58 PM)]



## [Setting the calendar display (Example: June 12 Monday)]



## [Time difference adjustment (reversion to normal time display)]

In case of time difference adjustment, press the **B** button instead of the **A** button and the watch reverts to the normal time display.

### (Independent correction)

Correction of any digit, if not required, can be skipped by pressing the **A** button repeatedly.

*Note: As the calendar system is set at 28 days for February, reset March 1 to February 29 in each leap year.*