



## [Operating the stopwatch]


### (a) Net time measurement



### (b) Lap time measurement




### (c) 1st-2nd place times



Regular timekeeping returns when the (C) button is pressed after using the stopwatch. However, the stopwatch mode works independently.

## [Setting time and calendar]



(Independent correction) Correction of any digit, if not required, can be skipped by pressing the (C) button repeatedly.

(Reversion to normal time display) The watch reverts to the normal time display if the (B) button is pressed, regardless of the digit setting mode.

(Automatic digit advance) When the (C) button is kept depressed for more than two seconds, the digit advances automatically. When released, the digit advance will stop.