



[Reading the display]



[Setting time and calendar]



Leap year number	Indicates	The year			
0	Leap year	1976	1980	1984	1988
1	Year after leap year	1977	1981	1985	1989
2	Two years after leap year	1978	1982	1986	1990
3	Three years after leap year	1979	1983	1987	1991